


KB-32 Washout Booth Instructions

Whats In The Box:



- A** 1 - Sink Pan
- B** 1 - Translucent Back panel
- C** 1 - Tube of Silicone
- D** 1 - Silicone Applicator Tip
- E** 2 - Side Panels
- F** 4 - Legs
- G** 4 - 1/4"-20 x 1" SS Pan Head Bolt
- H** 8 - 3/8"-16 x 1" SS Pan Head Bolt
- I** 10 - 1/4"-20 x 3/4" SS Pan Head Bolt

Tools Required:



- Phillips Screwdriver

1




- Take the sink pan and turn it upside down.
- Attach one leg at a time using two (**H**) bolts and a phillips screwdriver. **(DO NOT OVER TIGHTEN!)**
- Repeat the process for the other three legs.

2



- Stand the sink upright on all four legs.
- Attach one side panel to the inside of the sink pan using three (**I**) bolts. **(DO NOT OVER TIGHTEN!)**
- Note: Threaded inserts on the side panels should face the back of the sink.
- Repeat the process for the other side panel.

3



- Attach the translucent back panel to the bottom of the sink pan using four (**I**) bolts. **(DO NOT OVER TIGHTEN!)**
- Apply a thin bead of Silicone to the back of both side panels. (See Figure 2 marked in **Red**)
- Attach the translucent back panel to the side panels using four (**G**) bolts. **(DO NOT OVER TIGHTEN!)**



4



- Move sink to your desired location.
- Connect drain to 1-1/2" female coupler on sink per city and county regulations.



ANTHEM SCREEN PRINTING
SUPPLIES & SERVICES
WWW.ANTHEMSCREENPRINTING.COM

ORDER TODAY! 415.400.5466
ANTHEMSCREENPRINTING.COM