



Owner's Manual

WASH-IT



67-1420 REV 418

Table of Contents

I. Introduction & Features.....3

II. Parts for Assembly.....4

III. Assembly.....5

IV. Limited Warranty.....9

Introduction & Features

Congratulations on your purchase of the Wash-It Screen Wash Out/Reclaim Sink. We'd like to thank you for choosing Workhorse Products!

Please check the contents of the packaging for damages immediately. While our packaging has been designed to handle normal shipping conditions, we cannot foresee damages caused by the carrier and are not responsible for damages that occur during transportation.

If shipping damage has occurred, immediately contact the carrier to file a claim and contact Workhorse Products at 800-778-8779.

The Importance of the Owner's Manual:

The purpose of the Owner's Manual is to familiarize you with the parts and operations of the Wash-It. There are step-by-step instructions to set up this equipment as well as additional information that will help with the operation and maintenance.


Features

- Ideal for small to medium sized printers.
- Sturdy construction.
- Translucent back splash.
- Large screen capacity.
- Waterproof welded seams.
- Adjustable screen tray.
- Standard plumbing fitting.
- Complete draining.
- Easy to assemble.

Parts for Assembly

Carton Contents

- A -Two side splash panels
- B -One top splash panel
- C -Two screen stops
- D -Fastener bag
- E -Four wash sink legs
- F -One back leg brace and two side leg braces
- G- One sink base
- H- One Polypropylene back panel



4 Leg leveling feet

1/2" Nuts

1/2" Washers

1/2" Bolts

Silicone sealant



Assembly

Start with the four leveling feet. Screw the jam nut down until it contacts the top of the foot.

Screw the leveling feet into the bottom of the legs, as shown.



Remove the translucent back splash panel from the Wash-It sink base.



After installing the leveling feet to the legs, invert the wash sink base. Place one of the legs in a corner of the wash base with the smooth side facing out as shown. Loosely fasten the leg using a bolt, lock washer and nut.



Assembly

Loosely fasten the rest of the legs as shown.



Loosely fasten the leg braces between the two back legs and two front legs with the smooth side facing out using four bolts, washers, and nuts.

When all of the bolts, lock washers and nuts are in place securely tighten using a 1/2" wrench.



Place the Wash-It sink base and leg assembly on the floor.

Install one of the two side splash panels into the Wash-It sink base corner. The shorter side of the L shaped panel faces the center of the Wash-It sink. Loosely fasten with bolts, lock washers, and nuts. and put it into one of the corners.



Assembly

Attach the opposite side splash panel in the same manner.

After installing both side splash panels, insert the translucent back splash panel into the slots provided. Ensure the back panel is inserted until it contacts the lip on the Wash-It sink base. Note that the double wide Wash-It sink is supplied with two translucent back splash panels.

Securely tighten all fasteners using a 1/2" wrench.



Install the top splash panel. The lip on the top panel faces up and should be on the rear of the Wash-it sink as shown.

Align the bolt holes and insert three bolts on each side. Loosely fasten the bolts until all are installed, then securely tighten using a 1/2" wrench.



Assembly

After assembling the Wash-It sink, seal all bolts and seams from the inside of the sink using the provided silicone sealant.



Locate the Wash-It sink in the desired location.

Workhorse Products recommends that the drain connections be made by a licensed plumber.



OPTIONAL SQUEEGEE RACK

You can add this handy rack to your Wash-It sink! The rack hangs on the inside of the sink and holds up to 8 squeegees.



Limited Warranty

Although every effort has been made to provide accurate specifications, Workhorse Products does not assume any liability for damages, whether consequential or incidental, that may result from the use or misuse of the indicated specifications. Workhorse Products requires the use of a licensed industrial electrician for the installation of electrical service to equipment requiring electrical power.

Workhorse Products reserves the right to alter specifications in the manufacture of its products. It is understood and agreed that Seller's liability for any equipment whether liability in contract, in tort, under any warranty, in negligence, in strict liability or otherwise shall not exceed the return of the amount of the purchase price paid by Buyer. Notwithstanding the foregoing provision, under no circumstances shall Seller be liable for special, indirect or consequential damages. The price stated for the equipment is a consideration in limiting Seller's liability. No action regardless of form, arising out of the transactions under this Agreement may be brought by Buyer more than one (1) year after the cause of action has occurred. Our warranty is specified is exclusive and no other warranty, whether written or oral, is expressed or implied. Workhorse Products specifically disclaims the implied warranties of merchantability and fitness for a particular purpose. Equipment manufactured or sold by Workhorse Products is warranted against defects in workmanship and materials for a period of one year from receipt by customer. All warranties initiate from date of shipment to original customer. Replacement parts are covered for the term of the equipment warranty period. Parts not under warranty are covered for thirty (30) days from receipt by customer. Any part found by Workhorse Products to be defective in material or workmanship within the stated warranty period will be replaced or repaired at Workhorse's option without charge.

AFTER OBTAINING AN RMA# SEND RETURNED FREIGHT PREPAID TO 3730 E. Southern Avenue, PHOENIX, AZ 85040 USA.

Written authorization must be obtained from Workhorse before any part will be accepted. Replacement parts are sent out freight collect.

Parts sent out prior to receiving defective require a credit card hold for cost plus freight. Upon return of defective part, if it is deemed that the part was not damaged by customer but failed, the cost of the replacement part will be refunded.

This warranty does not extend to expendable parts such as filters, fuses, elements and brushes. Workhorse does not warrant failure of parts or components resulting from misuse or lack of proper maintenance. Installation, inspection, and maintenance costs are the sole responsibility of the purchaser.

Registration Form	
Company Name: _____	Contact Name: _____
Address: _____ _____	Phone Number: _____
City: _____	Fax Number: _____
State: _____	Email : _____
Country: _____	Cell Number: _____
Zip Code: _____	Serial Number: _____
Model Number: _____	Date Recivied: _____
Date Purchased _____	
Please Fax Registration Form for warranty to take place	