"TheEZGrip.com"

The Original 2 Handle Squeegee


INSTRUCTIONS

Video instructions available on the theezgrip.com website

1. BLADE ASSEMBLY



INSTALL: place the holder in your left hand, use your right hand to align one end of the blade to one end of the holder and push.





REMOVE: place the holder in your left hand, with your right hand peel the blade out of the holder's slot.

"The EZGrip.com" holds blade sizes up to 14", capable of producing crisp quality 13 1/2" wide imprints.

Designed to fit MOST Blades.

Blade too narrow: doesn't fit tight, simply lay a strip of 2" masking tape centered along the length of the blade. Wrap the tape over both linear sides of the blade, then insert the tape covered portion into the blade slot. **Blade too thick**: first coat blade's edge with water & soap before installing.





2. HOW TO USE

GRIP METHOD




LAYING ON SCREEN



HANDLES STAY CLEAN



ON TABLE TOP



3. CLEANING

WIPE with clean cloth. "TheEZGrip.com" is made of chemical resistant composites. Most chemicals commonly used for removing ink will not harm the holder's surface.